

AVC Remote Control Guide



Copyright Notice

© Amino Communications Ltd. All rights reserved. Printed in China. Amino, AmiNET and AmiNET530 are trademarks of Amino Communications Ltd. All other product or brand names as they appear are trademarks or registered trademarks of their respective holders. This document contains proprietary information of Amino Communications Ltd ("Amino") No part of this document may be copied, reproduced, transmitted, distributed, transcribed, stored in a retrieval system, modified or translated into any other language or computer language, or sublicensed in any form or by any means - electronic, mechanical, magnetic, optical, chemical, manual or otherwise - without the prior written consent of Amino.

Disclaimer

Amino shall not be liable for any errors contained herein nor for any damages arising out of or related to this document or the information contained within it, even if the Company has been advised of the possibility of such damages. This document is intended for informational and instructional purposes only. The Company reserves the right to make changes to the specifications and other information contained in this document without prior notification.

Product Disposal Information - EU only

The product is labelled in accordance with the European Directive 2002/96/EC concerning Waste Electrical and Electronic Equipment (the WEEE Directive) and therefore should not be disposed of with other household or commercial waste.



Product Disposal Instructions for Residential Users

Please remove any batteries and dispose of them and the product as per your local authority's recycling processes. For further information please contact your local authority or the retailer where the product was purchased.

Product Disposal Instructions for Business Users

Business Users should contact their supplier and check the terms and conditions of the purchase contract and ensure that the product is not mixed with other commercial waste for disposal.

Contents

**Setting up the AVC
Remote Control**

4

**Controlling the
Set-Top Box**

6

**Configuring the
Remote Control**

8

TV Brand Codes

9

DVD Brand Codes

15

AVC Remote Control Guide

3

Setting up the AVC Remote Control

This section explains how to unpack and set-up the Amino remote control.


Your service provider may have supplied an alternative remote control, in which case please refer to the User Guide supplied by your service provider for instructions on setting up and using the remote control.

Inserting Batteries

The remote control requires two batteries type AAA, MN2400, UM-4, or LR03.

For best performance we recommend using Alkaline batteries.


- Open the battery cover by pushing lightly on the tab and lifting up the cover:
- Insert the batteries, taking care to observe the correct polarity:
- Replace the battery cover by engaging the two tabs in the top of the case and then closing it until it clicks into place:



Childproof Feature

You can optionally secure the battery compartment with the screw provided to prevent children from opening the compartment:

- Remove the battery cover as described above, and using a suitable screwdriver remove the silver screw at the base of the remote control:



- Replace the battery cover.
- Fit the screw at the base of the cover, taking care not to overtighten it.

Important Information about Using Batteries

Do not mix different types of battery or old and new batteries.

Do not use rechargeable batteries with the remote control.

Remove the batteries from the remote control if you are not going to use it for several weeks, to avoid the risk of leakage.

Please respect your environment and any local regulations and dispose of old batteries in a responsible manner.



Caution!

Do not attempt to recharge the batteries.

Immediately remove any leaking batteries. Take care when handling leaking batteries as they may cause burns to the skin or eyes, or other physical injuries.

Controlling the Set-Top Box

To control the Set-Top Box (STB) press the **STB** button on the remote control. The **STB** mode-select button will light for one second to indicate that the mode has been set.

When any valid function button on the remote is pressed, the **STB** button will light to indicate that a command is being transmitted in STB mode.

Switching On or Off

To turn the STB on or off:

- Press the power button on the Amino remote control.

When the STB is switched on the status light on the front panel is on.

Controlling a TV

To control the TV press the **TV** button on the remote control. The **TV** mode-select button will light for one second to indicate that the mode has been set.

When any valid function button on the remote is pressed, the **TV** button will light to indicate that a command is being transmitted in TV mode.


Controlling the DVD

To control the DVD press the **DVD** button on the remote control. The **DVD** mode-select button will light for one second to indicate that the mode has been set.

When any valid function button on the remote is pressed, the **DVD** button will light to indicate that a command is being transmitted in DVD mode.

Using the Remote to Control the Set-Top Box, TV, or DVD

The function of unlabelled buttons may vary depending on the service provider.



Configuring the Remote Control

In order for the remote control to transmit the correct signals to control the TV, the remote control must be programmed with a code corresponding to the brand of TV in use. Below is a set of instructions for programming TV codes into the remote:

- Identify the make of the TV; e.g. Sony, Philips etc.
- Find the TV manufacturer in the TV brand code tables in this manual. Most TV manufacturers have more than one brand code listed; if this is the case use the steps below to try all the brand codes until a suitable one is found. If no brand code exists for your manufacturer, try using other popular brand codes.
- Press the TV Mode button and hold for 2.5 seconds.

The TV button will blink twice.

- Continue to hold down the TV mode button for another 2.5 seconds.

The TV button will blink twice again.

- Release TV mode button.
- Enter the 3-digit TV brand code from the list in this manual.

At each key press the mode button will blink.

If the TV brand code is accepted, the TV button will flash twice and go out when the 3rd digit is entered.

If the TV brand code is not accepted, the TV button will remain illuminated for 2.5 seconds and then go out. The remote control will not have been programmed and the process will have to be repeated from the start.

During the programming steps if no button is pressed for 10 seconds, the TV button light will go out, the remote control will not have been programmed, and the process will have to be repeated from the start.

The same procedure applies to configuring the remote control in DVD mode.

TV Brand Codes

A.R. Systems 506 550
Abex 098
Acer 041
Acme 373 388
Acura 379 500
ADA 378
ADC 372 374
Admiral 001 099 207 214 370 371
372 386 387 440 514 557
Advent 113 197
Adventura 100
Adyson 373 492 493 527 528
Agashi 492 493
Agazi 372
AGB 448 498
Aiko 015 206 373 374 379 492 493
500 504 506 512 527 528
Aim 506
Aiwa 034 340 662
Akai 002 201 222 333 374 376 378
379 380 408 416 457 463 475 492
493 498 500 504 506 512 528 529
561 567 573
Akiba 380 506 529 540 558
Akito 390
Akura 372 380 417 500 506 529 540
Alaron 492
Alba 373 379 380 392 393 412 416
424 475 492 497 500 505 506 527
529 536 552 557 576 695
Alcyon 513
Alkos 472
Alleron 044
Allorgan 391 493 528 542
Allstar 408 506
America Action 211

Amplivision 373 493 497 528 543 555
Amstrad 372 379 380 395 416 417
440 448 498 500 506 521 529 551
Amtron 036
Anam 211 379 414
Anam National 003 036
Anglo 379 500
Anitech 372 379 403 500 506 513
Ansonic 379 382 496 497 500 503
506 515 536 538 541 556
AOC 004 005 155 201
Apex 074 088 111 119 229
Apex Digital 208 216 334
Apollo 560
Arc en Ciel 404 451 461 545
Arcam 492 493 527 528
Arcam Delta 373
Aristona 408 475 503 506 567
Arthur Martin 555
ASA 370 383 384 385 387 511 516
548
Asberg 403 408 506 513
Astra 379
Asuka 372 373 380 492 493 527 528
529 540
Atlantic 373 408 475 492 506 527
538 543
Atori 379 500
Auchan 555
Audiosonic 373 379 380 408 461 475
493 497 506 528 529 547
AudioTon 373 493 497 528
Audiovox 036 206 211 213 344
Ausind 403 513
Autovox 370 372 373 403 435 450
493 513 528 536 549
Aventura 209
Awa 492 493 502
Ayomi 533
Baird 441 461 493 512 523 524 528

Bang & Olufsen 370
Basic Line 379 380 408 493 500 506
529 540
Bastide 373 493 528
Baur 419 445 456 463 475 501 506
525 549 565
Bazin 493 528
Beko 377 398 424 497 506 636 639
648 682 691
Belcor 155
Bell & Howell 001 045 163 221
Benq 042 136
Beon 408 475 506 557
Best 497 547
Bestar 408 443 497 506
Binatone 373 493 528
Black Star 453 536
Blacktron 540
Blackway 540
Blaupunkt 378 458 525
Blue Sky 380 506 529 540 558 576
Blue Star 446 540
Bondstec 453 536
Boots 373 390 493 528
BPL 446 506 540
Bradford 036 211
Brandt 400 404 405 451 452 461 545
546 582 583
Brinkmann 506 557
Brionvega 370 408 475 506
Britannia 373 492 493 527 528
Brockwood 155
Broksonic 114 121 211 214 333 363
Bruns 370 377
BSR 391 455 542
BTC 380 529
Bush 379 380 386 389 390 392 393
408 412 416 443 446 455 456 461
474 475 476 493 500 505 506 528

529 540 542 549 552 566 576 609
668 688
Candle 004 007 100 155 201
Capsonic 372
Carena 506 558
Carnivale 201
Carrefour 392 505 511
Carver 205
Cascade 379 500 506
Cathay 408 475 506
CCE 493
Celebrity 002 199
Celera 216
Centurion 156 408 475 506
Century 370 536
CGE 403 453 455 497 513 536 557
Changhong 216
Cimline 379 393 500 529
Citizen 004 007 015 036 073 097 155
163 201 206 362
City 379 500
Clarion 211
Clarivox 475
Clatronic 372 373 379 380 395 403
408 424 453 493 497 500 506 513
515 528 529 536 543
CMS 492 493
Colortyme 004 155
Colt 358
Commercial Solutions 202
Concerto 004 155
Concorde 379 500
Condor 373 408 424 492 497 500
506 515 527 536 540 543 556
Contec 211 373 379 392 394 395
492 500 502 505 519 527
Contec/Cony 002 011 012 036
Continental Edison 400 404 405 441
451 461 545
Cosmel 379 500 547

Craig 036 211
 Crosley 205 370 403 453 455
 513 536
 Crown 036 053 211 379 403 408
 424 475 497 500 506 513 557 568
 CS Electronics 373 380 453 492
 527 529 536
 CTC 382 453 536
 Curtis Mathes 000 004 005 014
 045 073 097 154 155 163 201
 202 205 207 213 220 221 222
 CXC 036 211
 Cybertron 380 529
 Daewoo 002 004 005 013 015 016 097
 106 135 155 193 206 213 259 362 373
 379 408 410 432 443 487 492 493 500
 506 527 528 529 564 592 610 640 708
 Dainichi 380 492 527 529
 Dansai 372 408 475 492 493 504 506
 527
 Dantax 398 427 475 476 497
 Dawa 506
 Daytron 004 097 155 379 500
 De Graaf 376 386 397 508 532
 Decca 373 374 390 395 408 448 475
 493 498 506 512 528
 Dell 141 142 146
 Denon 220
 Desmet 408 475 506 543
 Diamant 506
 Diamond 492
 Dimensia 000 154
 Dixi 379 408 475 493 500 506
 DTS 379 500
 Dual 373 428 450 451 455 461 470 493
 506 528 538 549 550 566
 Dual-Tec 373 379 455 528 538
 Dumont 155 200 370 373 382 384 385
 493 511 515 528
 Durabrand 198 209 210 211 214

Dux 475
 Dwin 207
 Dynatron 408 475 506
 Elbe 440 493 496 497 498 506 529
 533 538 541 556 572
 Elcit 370 498 515 536
 Electa 446
 Electro Tech 379
 Electroband 002 199
 Electrograph 218
 Electrohome 002 003 004 018 021
 155
 Elektra 540
 Elin 373 383 385 408 475 492 500
 506 516 527 549
 Elite 380 408 506 529
 Elman 382 455 515
 Elta 379 492 500
 Emerson 004 005 011 013 025 031
 033 036 044 045 080 097 102 107
 155 163 191 209 210 211 214 221
 337 362 363 370 452 463 497 506
 511 521 536
 Emperor 540
 Envision 004 155 201
 Epson 217
 Erres 408 475 503 506
 ESA 209
 ESC 493
 Etron 379
 Euro-Feel 372 493
 Euroline 427 466 475
 Euroman 372 373 408 492 493 497
 506 527 528 540
 Europhon 373 382 390 408 448 455
 492 493 498 506 515 528 536
 Expert 538 555
 Exquisit 506
 Fenner 379 443 500

Ferguson 399 400 407 409 422 441
 452 471 475 523 524 533 546 606
 Fidelity 373 386 416 492 506 527
 Filsai 493
 Finlandia 376 386 548
 Finlux 370 373 374 382 383 384 385
 403 408 448 455 474 475 493 498
 506 511 512 513 515 516 522 528
 548 556
 First Line 373 379 391 408 412 453
 492 493 500 506 512 515 527 528
 533 536 542 544 549 556 576
 Fisher 043 045 047 103 157 163 221
 370 373 376 385 392 394 401 424
 455 493 497 505 509 512 519 528
 549
 Flint 408 506 512 529 558
 FNR 515
 Formenti 370 371 373 403 450 455
 457 475 492 513 527 543
 Fortress 370 371 514
 Fraba 497 506
 Friac 497
 Frontech 372 379 386 387 416 445
 453 493 500 536 549
 Fujitsu 029 044 308 309 310 311
 374 493 512 515 528
 Funai 036 044 046 209 211 317
 357 372 391 522 542
 Futuretech 036 211
 Galaxi 424 506 515
 Galaxis 497 506 515 557
 Gateway 038 218 223
 GBC 379 392 455 500 529
 GE 000 002 003 004 008 021 048
 049 063 068 070 143 144 154 155
 202 203 210 213 281 359 360
 Geant Casino 555
 GEC 373 374 387 402 408 448
 456 463 475 493 498 506 507 512
 528 549

Geloso 379 386 455 500 536
 General 559
 General Technic 379 500
 Genexxa 380 387 408 506 529
 Giant 493
 Gibraltar 155 200 201
 GoldHand 492
 Goldline 506
 Goldstar 004 005 011 018 050 090
 091 097 098 155 201 210 361 373
 379 381 386 408 425 431 453 455
 475 476 492 493 494 497 500 506
 527 528 536 554
 Goodmans 372 374 379 392 393
 408 416 431 441 443 452 475 493
 494 498 500 504 505 506 512 522
 528 561 564 567
 Gorenje 424 497
 GPM 380 529
 Graetz 387 463 464
 Granada 373 374 376 386 392 396
 401 403 408 413 448 452 457 460
 475 493 498 503 505 506 509 512
 513 517 528 531 546 553 555 560
 Grandin 379 380 446 475 540
 Gronic 493
 Grundig 378 384 403 430 435 442
 444 458 459 497 506 511 513 525
 567 585 646
 Grunpy 036 044 211
 Haier 198
 Halifax 372 373 492 493 527 528
 Hallmark 004 155 210
 Hampton 373 492 493 527 528
 Hanseatic 373 377 379 391 392 408 445
 455 463 475 493 496 497 500 506 528
 540 541 542 543 549 566
 Hantarex 379 448 498 500 506
 Hantor 506
 Harley Davidson 357
 Harman/Kardon 205

Harvard 036 211
Harwood 500 506
Havermy 207
HCM 372 373 379 446 493 500 506
528 529 540 557
Hello Kitty 213
Hema 493 500 528
Hemmermann 549
Hifivox 461
Higashi 492
HiLine 506
Hinari 376 379 380 392 403 408 475
500 505 506 522 529 552
Hisawa 380 446 529 540 555 558
Hisense 112 215
Hitachi 002 004 011 012 030 051 084
085 086 102 132 133 134 155 220
225 231 316 320 323 326 328 329
331 357 373 374 383 386 387 388
392 397 402 404 405 406 426 445
448 455 457 460 461 462 463 464
465 493 498 505 506 507 508 512
516 518 528 530 532 549 553 560
562 564 610 633 635 656 658 659
694
Hornophon 408 506
Hoshai 380 529 558
Huanyu 373 443 492 527
Hygashi 373 492 493 527 528
Hyper 373 379 453 455 492 493 500
527 528 536
Hypson 372 373 408 446 475 493
506 528 540 555 558
Iberia 506
ICE 372 373 379 380 408 416 492
493 500 506 527 528 529
ICeS 492 527 529
IMA 036
Imperial 387 403 408 424 453 455
497 506 513 536 549 557
Indesit 389 435

Indiana 408 475 506
Infinity 053 205
Ingelen 387
Ingersol 379 500
Inno Hit 373 374 379 380 408 431
448 475 493 494 498 500 506 512
513 528 529 536
Innovation 372 379 415 416 441 443
476 478
Inteq 200
Interactive 497
Interbuy 379 453 500 536
Interfunk 370 387 408 453 461 463
475 497 503 506 539 565
International 492
Intervision 372 373 382 493 497 506
515 528 529 536 540 554 558 566
Irradio 379 380 408 416 475 494 500
506 513 529 536
Isukai 380 506 529 540
ITC 373 455 493 528
ITS 380 408 416 446 492 506 527
529 540
ITT 379 387 396 456 457 463 464
522 548 549 560 561
ITV 379 427 475 476 506 536
Janeil 100
JBL 053 205
JC Penney 000 002 004 005 007 012
021 048 049 058 063 068 072 073
075 097 098 154 155 194
JCB 002 199
JEC 472 504
Jensen 004 155 197
JVC 002 011 012 026 049 054 055
080 117 130 131 204 261 341 392
408 416 422 505 510 523 524 529
570 575 666 669 686 689
Kaisui 373 379 380 446 492 493 500
506 527 528 529 540 558
Kamosonic 373

Kamp 373 492 527
Kapsch 387 538
Karcher 373 379 383 475 497 506
515 540 572
Kawasho 002 004 155 492
KEC 211
Kendo 382 386 393 440 497 506 515
536 556 572
Kennedy 455
Kenwood 004 018 155 201 349
KIC 493
Kingsley 373 492 527
KLH 216
Kloss Novabeam 036 056 057 100
Kneissel 496 497 506 533 538 541
556
Kolster 408 506
Konka 219 380 529
Korpel 408 475 506
Korting 370 497 543
Kosmos 506
Koyoda 379
KTV 036 097 161 201 211 373 493
Kyoto 492 493
Lasat 497
Lenco 379 500
Lenoir 373 379 500
Lesla 453 536
Leyco 372 374 391 408 475 506 512
542 568
LG 005 210 373 379 381 386 408
425 427 431 453 455 466 475 476
492 493 494 497 500 506 527 528
536 554 652 657 677 687 696 706
LG/GoldStar 677
Liesenk 475
Liesenkotter 506
Life 372 379 415 416 441 443 476
478

Lifetec 372 379 415 416 441 443 476
478 500 506 529 566 576
Lloyd's 357 500
Loewe 053 433 434 496 497 498 506
541 565 588 630 634
Loewe Opta 370 408 475
Logik 001 395 502
Luma 386 463 475 500 506 538 556
Lumatron 386 408 463 475 493 506
528 538
Lux May 408
Luxman 004 155
Luxor 373 386 406 431 435 456 460
463 493 494 549 553 561 563
LXI 000 004 045 053 058 068 075
154 162 163 202 205 208 210 221
M Electronic 373 379 383 385 387
400 408 416 443 461 475 561 563
Magnadyne 370 382 448 453 455
475 498 515 536
Magnafon 373 382 403 448 492 498
513 515 527
Magnasonic 362
Magnavox 004 007 018 053 056 057
059 060 110 147 155 164 169 195
201 205 232 233 312 357
Magnin 359
Magnum 372 379 415 416 441 443
476 478
Majestic 001
Mandor 372
Manesth 372 373 393 408 475 493
504 506 528 542 543
Marantz 004 051 053 155 165 201
205 313 408 475 506
Marelli 370
Mark 408 475 492 493 500 506 527
528
Masuda 493
Matsui 373 374 379 386 390 391 392
393 395 408 412 416 430 448 472

475 493 498 500 502 504 505 506
509 512 521 525 528 542 546 549
551 552 558 567 568

Matsushita 212 414

Maxent 218

McMichael 402 507

Mediator 408 475 503 506 567

Medion 372 379 415 416 443 476
478 506 576

Megatron 004 051 210 220

M-Electronic 492 493 500 506 516
527 528 536 548 556 565

Melvox 555

Memorex 001 004 005 022 045 046
163 210 214 221 351 361 379 500

Memphis 374 379 500 512 547

Mercury 500 506

Metz 370 418 458 467 468 525 534
539

MGA 002 004 005 018 021 047 061
155 166 201 210 359

Micromaxx 372 379 415 416 441 443
476 478

Microstar 372 379 415 416 441 443
476 478

Midland 049 068 097 098 200 202
203

Minerva 384 435 458 498 511 513
525

Minoka 408 506

Minutz 048

Mitsubishi 002 004 005 018 021 032
047 061 155 166 167 192 207 210
270 272 313 319 360 370 392 395
408 434 435 458 505 506 517 551
565 660 679

Mivar 373 403 431 448 492 493 494
495 496 497 498 499 513 527 541
571

Montgomery Ward 001

Motion 403 513

Motorola 003 099 207

MTC 004 005 073 155 201 456 492
497 549

Multi System 475

Multistandard 515

Multitech 036 211 373 379 382
386 392 403 404 453 455 475
492 493 497 500 506 515 527 528
536 549

Multivision 158

Murphy 373 385 457 492 512 527

NAD 004 058 075 085 160 162 208
210 463

Naonis 386 440

National 413 435 526

NEC 003 004 005 155 201 392 481
493 505 520 543

Neckermann 370 373 378 386 408
424 445 456 475 493 497 501 506
528 536 549 556 557 567

NEI 408 416 475 506 547

Nesco 453 522 536

NET-TV 040 218

Network 547

Neufunk 500 506 567

New Tech 379 408 493 500 506 528
567

New World 380 529

Nicamagic 373 492 527

Nikkai 372 373 374 380 408 472
475 492 493 500 504 505 506 512
527 528 529 547

Nikko 004 015 201 206 210

Nobliko 373 382 384 403 492 511
513 515 527

Nogamatic 461

Nokia 387 396 456 457 463 464 548
549 560 561 563 573

Norcent 215 302

Nordic 493

Nordmende 370 387 389 400 404
405 408 441 451 452 461 525

Nordvision 475

Novatronix 506 516

NTC 015 206

Oceanic 387 463 464 542 555

Okano 424 497 506 512

Onceas 373

Onwa 036 211 529

Opera 506

Optimus 085 160 212 221 351

Optonica 064 099 207

Orbit 408 506

Orion 023 033 107 214 363 379 391
393 395 408 412 418 448 464 475
476 498 500 502 506 515 521 542
543 544 552 636

Orline 506 529

Ormond 476

Orsowe 498

Osaki 372 373 374 380 473 493
506 512 528 529

Osio 494

Oso 380 529

Osume 374 394 505 512 519 529

Otto Versand 371 373 378 392
408 419 441 445 446 455 456
461 463 475 493 498 501 505
506 514 525 528 531 536 542 543
549 565 567

Pael 373 492 527

Palladium 373 381 424 493 497
501 506 528 536 549 556 557 567

Palsonic 493

Panama 372 373 379 473 492 493
500 506 527 528 536

Panasonic 003 010 046 049 053
096 123 140 152 203 212 226 235
242 246 247 248 250 258 265 271
273 274 291 292 322 336 339 346
348 350 351 364 365 366 367 369
387 413 414 415 435 449 463 464
467 468 482 489 498 506 526 531
537

574 580 587 594 598 600 602 619
625 632 644 680 701

Panavision 506 556

Pathe Cinema 373 455 492 496 497
527 533 541 543 549 555

Pathe Marconi 404 405 451 461 545

Pausa 379 500

Penney 201 202 203 208 210 359 361

Perdio 374 492 506 512 543

Perfekt 506

Philco 003 004 005 007 011 018 053
056 057 059 155 164 201 205 370
403 453 455 497 506 513 536 557

Philharmonic 373 473 493 528

Philips 003 007 011 017 018 053 056
057 059 063 095 126 129 148 155 168
169 170 205 228 232 233 263 264 275
276 277 280 338 347 370 373 402 403
408 427 428 441 443 455 463 469 475
490 491 503 506 507 567 579 581 584
586 590 593 595 596 597 604 608 611
612 613 616 617 620 627 641 647 649
654 663 674 683 685 690

Philips Magnavox 148 228 232 233 264

Phoenix 370 408 475 492 497 506 512
527 543

Phonola 370 408 475 492 503 506 527
567

Pilot 097 155 201

Pioneer 004 035 085 102 155 160 171
172 173 196 268 387 400 408 461 475
497 506 703

Plantron 372 408 500 506

Plasmsync 313

Playsonic 493 528

Polaroid 216 298

Poppy 379 500

Portland 004 005 015 097 155 206

Prandoni-Prince 386 448 463 498
513 536
Precision 373 473 493 528
Price Club 073
Prima 113 197 379 387 500
Prinz 406 512 549
Prism 049 203
Profex 379 403 463 500
Profilo 476
Profi-Tronic 408 506 515
Proline 374 408 412 503 506 512 544
Proscan 000 008 068 154 202
Prosonic 373 475 476 492 493 497
506 526 527 568
Protech 372 373 379 382 408 453
455 456 473 475 493
Proton 004 011 155 174 210
Provision 475 476 506 564
Pulsar 155 200
Pye 408 416 475 503 506 567 653
693
Pymi 379 500
Quandra Vision 555
Quasar 003 039 046 049 062 069 161
175 203 212 351 453
Quelle 372 373 383 384 385 391 395
408 419 453 455 458 463 475 476
493 494 501 502 505 506 511 516
519 525 528 536 549 565
Questa 392 505
Radialva 506 529
Radio Shack 000 045 163 221 201
202 210 211 357 506
Radio Shack/Realistic 004 011 036
045 064 097 098 154 155 163
Radiola 408 475 493 503 506 567
Radiomarelli 370 448 453 498
506 536
Radionette 383 385
Radiotone 377 408 497 500 506 557
568

Rank 384 392 511
RBM 384
RCA 000 003 004 005 008 018 028
052 065 067 068 071 076 082 102
104 106 108 115 143 151 154 155
176 177 178 179 196 202 224 262
281 283 330 335 342 359 360 396
Realistic 000 045 163 201 210 211
221
Recor 506
Rediffusion 463
Redstar 506
Reflex 506
Revox 408 475 497 506
Rex 372 386 387 440 536 538 556
RFT 370 377 496 497 512 541
Rhapsody 492
R-Line 408 475 506
Roadstar 372 379 380 500 529 557
698
Robotron 370
Rowa 492 493
Royal Lux 497
RTF 370
Runco 200 201
Saba 370 387 400 404 405 410 441
448 451 452 461 463 464 498 546
582 583 684
Sagem 558 572
Saisho 372 373 379 393 395 448 493
498 500 502 521 528 551
Salora 386 387 396 406 431 440 445
455 456 460 463 494 498 549 553
Sambers 382 403 448 498 513 515
Sampo 004 097 098 120 155 201 218
Samsung 004 005 011 014 018 019
072 073 078 094 097 098 155 180
201 210 222 244 269 307 324 343
354 368 285 288 289 290 294 295
301 305 307 343 368 372 373 374
379 395 408 424 429 431 437 438
470 473 475 477 488 492 493 494

497 500 506 512 527 528 567 569
614 618 631 637 642 705
Sandra 373 492 493 527 528
Sansui 023 107 122 214 234 333 357
363 408 506
Sanyo 045 103 155 157 163 166 181
182 221 318 359 373 374 376 383
385 392 394 395 396 401 403 452
455 470 492 493 496 497 500 502
505 509 512 519 527 528 541 624
676 678 700
SBR 402 475 503 506 567
SCHAUB LORENTZ 387 463 464
Schaub Lorenz 549
Schneider 373 380 408 416 417 450
455 461 470 475 478 493 503 506
528 529 536 538 549 550 566 567
576 655 671 673 681
Scotch 004 210
Scott 004 011 033 036 044 155 210
211
Sears 000 002 004 012 018 044 045
047 055 058 068 075 103 105 154
155 157 162 163 183 184 202 205
208 209 210 221 357 361
SEG 372 373 382 392 403 427 453
455 475 492 493 500 505 506 517
527 528 536 576
SEI 498 501 506 515 542 549
SEI-Sinudyne 370 382 387 391 418
448 498 521
Seleco 386 387 392 440 455 538 556
Sencora 379 500
Sentra 472 500 504 529
Serino 492 558 572
Sharp 004 009 011 025 032 064 077
092 097 099 138 153 155 185 186
190 207 245 282 286 293 296 371
375 392 394 411 483 484 498 505
510 514 519 542 591 603 623 626
650 664 675 702
Sheng Chia 207
Shogun 155

Shorai 391 522 542
Siarem 370 382 448 455 498 506 515
519 525
Siemens 378 394 458
Sierra 408 503 506 567
Siesta 470 497
Signature 001 187
Silva 492 527
Silver 392 505 522
Simpson 007
Singer 370 382 453 455 515 536 555
Sinudyne 370 382 391 393 418 455
475 498 501 506 515 521 542 549
Skantic 387 460 553
Sogera 543
Solavox 387 512
Sonitron 376 396 493 497 528
Sonoko 372 373 379 408 475 493
500 506 528 540
Sonolor 376 387 501 555
Sontec 408 470 475 497 506 542
Sony 002 037 109 128 137 199 227
230 236 240 251 255 279 284 287
304 306 327 332 356 357 374 379
392 394 395 419 439 452 454 473
479 480 501 502 505 515 577 578
589 599 605 615 629 643 661 667
699
Sound & Vision 380 382 515 529
Soundesign 004 007 036 044 155
210 211
Soundwave 408 475 506 543 557
Squareview 105 209
SSS 036 155 211
Standard 373 379 380 408 473 493
500 506 528 529 543
Starlite 036 211 475 500 506
Stenway 446 529 540
Stern 386 387 538
Strato 500 506
Stylandia 493

Sunkai 379 391 412 529 542 544 552 558
 Sunstar 500 506
 Sunwood 379 408 500 506
 Superla 373 492 493 498 527
 Superscan 207
 SuperTech 445 492 500 506 527 567
 Supra 379 500
 Supre-Macy 100
 Supreme 002 199
 Susumu 380 546
 Sutron 379 500
 Sydney 373 473 492 493 527 528
 Sylvania 004 007 018 027 046 053 056 057
 059 060 124 145 150 155 164 169 188 201
 205 209 260 337
 Symphonic 024 031 036 105 209 211 357
 Sysline 475
 Sytong 492 527
 Tandberg 391 547 556
 Tandy 099 207 371 373 374 380 387 457 473
 493 512 514 528 529 536
 Tashiko 373 386 392 402 473 492 493 505
 507 520 527 528
 Tatung 003 223 373 374 390 408 448 473 475
 493 498 502 506 512 528
 TCM 372 379 415 416 441 443 476 478
 Teac 493 506 558 565
 Tec 373 379 453 455 457 473 493 500 528
 536 546 547 559
 Technema 543
 Technics 049 203 212 414
 Techwood 004 049 155 203
 Tedexlex 493
 Teknika 001 002 004 005 007 011 012 015
 036 044 060 073 096 097 155 205 206 211
 Teleavia 400 404 441 451 461 545

Telecaption 159
 Telecor 493 506 528 529 538
 Telefunken 222 399 400 407 408
 409 420 421 435 440 441 451 452
 461 471 486 506 546 559 697 704
 Telegazi 506 529 538
 Telemeister 506 543
 Telesonic 506
 Telestar 506
 Teletech 379 427 453 475 500
 506 536 547
 Teleton 373 445 456 473 493 505
 528 538 539 549
 Televideon 492 527 543
 Televiso 555
 Temco 542
 Tensai 379 380 385 391 408 493
 500 506 516 528 529 536 542 543
 554
 Tenson 543
 Tesmet 408
 Tevion 372 379 415 416 441 443
 476 478
 Texet 373 473 492 493 500 528
 Thomas 357
 Thomson 373 400 404 405 407 408
 409 410 435 436 441 451 452
 461 471 481 506 545 546 559 582
 583 607 707
 Thorn 374 385 399 422 441 452
 463 472 475 506 523 524 533 546
 564 565
 TMK 004 155 210
 TNCi 200
 Tokai 374 408 493 506 512 528 547
 Tokyo 373 492 504 527
 Tomashi 446 540
 Toshiba 006 045 058 073 075 079
 083 087 093 101 116 127 159 162
 163 183 208 221 237 238 239 241
 243 249 252 253 256 257 266 267
 300 313 315 321 325 333 345 353

354 355 384 392 423 442 472 485
 493 504 505 511 515 535 601 621
 622 628 638 645 651 665 670 672
 692
 Totevision 097
 Towada 387 455 493 515 549
 Trakton 493
 Trans Continens 493 506 528
 Transtec 492
 Trident 473 493 498 528
 Tristar 529
 Triumph 423 448 498 506 521 535
 548 567
 TVS 214
 Uher 387 403 408 497 506 513 538
 543 557
 Ultravox 370 373 382 453 455 457
 492 506 515 527 536
 Unic Line 506 560
 United 427 475
 Universal 048 063
 Universum 372 383 385 408 424 436
 447 453 455 475 493 494 497 501
 502 505 506 511 513 516 519 521
 525 528 536 542 547 548 549 556
 557 560 561 563 565 573
 Univox 506 533 547
 Vector Research 201
 Vestel 386 387 408 424 453 455 460
 475 476 493 506 528
 Vexa 379 475 500 506
 Victor 055 204 392 408 414
 Videologic 492
 Videologique 373 380 492 493 527
 528 529
 Videosat 453
 VideoSystem 408 506
 Videotechnic 492 493 527 528 543
 Videoton 553
 Vidikron 205

Vidtech 004 005 155 210
 Viewsonic 038 149 218 297 299 316
 Viking 100
 Visiola 373 492 527
 Vision 408 493 506 543
 Vistar 457
 Vizio 223
 Vortec 408 475 506
 Voxson 370 386 387 403 408 440 506
 513 557
 Waltham 373 457 460 473 493 506 528
 553 557
 Wards 000 001 004 005 018 031 044
 048 053 056 057 059 060 063 064
 154 155 169 189 201 205 210
 Watson 408 475 506 529 543 566 568
 Watt Radio 373 382 455 492 515 527
 549
 Waycon 208
 Wega 370 392 505 506
 Wegavox 500
 Weltblick 408 475 493 506 543
 Westinghouse 199 213 303
 Weston 455
 White Westinghouse 005 013 214 373
 382
 403 475 492 506 527 543 547
 Windstar 540
 Xrypton 506
 Yamaha 004 005 018 155 201
 Yamishi 493 506 528 529 540 558
 Yokan 506
 Yoko 372 373 379 380 408 473 475
 492 493 497 500 506 528 529
 Yorx 380 529
 Zanussi 386 440 493 528
 Zenith 001 020 081 089 118 125 155
 200 206 210 214 254 278 314 323 329
 352 357 363

DVD Brand Codes

Advent 163
Aiwa 026 131 134 309 348 466
Akai 146 162 300 340
Akura 388
Alba 409 412 413 431
Alco 160
Alpine 258
Amphion MediaWorks 167 171 264
AMW 167 171
Apex 001 056 057 095 098 145 273 360
Apex Digital 148 178 179 180 183 184 193 195 221 271 301
Aspire Digital 166
Audiovox 132 160 227 263 316
Best Buy 384
Blaupunkt 136 195
Blue Parade 191
Bose 122 130
Bosston 378
Brandt 370 408 423
Britannia 374
Broksonic 053 054 072 146 300
Bush 003 371 373 382 386 415 431 433 438 486
California Audio Labs 157
Cambridge Audio 376 393
CAT 379 380
Celestial 391
Centrex 389
Centrum 380
CGV 376
CineVision 385
Clarion 100
Classic 101 354
Clatronic 382

Coby 164 165 168
Conia 371
Crypto 387
C-Tech 377
CyberHome 083 405 417 419 429
Daewoo 058 062 137 138 325 326 327 418 456
Dalton 392
Dansai 375
Daytek 264 406
DEC 382
Denon 040 110 133 157 197 202 238 252 254 257 259 335 359 394 459
Denver 352 382 388
Denzel 372
Desay 381
Diamond 376 377
Digitor 390
Disney 194
DK Digital 003 443
Drmtch 323
Dual 372
DVD2000 188
DVX 377
Easy Home 384
Eclipse 376
Elta 336 353 427 433
Emerson 059 073 147 194 304 346
Enzer 372
Finlux 376
Fisher 112 134 349
Funai 194
Gateway 272
GE 041 079 118 189 195 255
Global Solutions 377
Global Sphere 377
Go Video 046 124 127 128 129 150 177 185 272 295 299 338
GoldStar 410

Goodmans 382 386 389 404 409 438
GPX 114
Gradiente 157
Graetz 372
Greenhill 195
Grundig 190 341 351 389 430 439
H&B 382 383
Haaz 376 377
Harman/Kardon 125 267 268 365
HiMAX 384
Hitachi 000 027 126 175 200 338 357 372 384 440 450 462 468
Hiteker 193
Humax 448
Initial 195
Innovation 342 343 344 357
Insignia 289
Integra 158 191
Irradio 017
JBL 043
Jensen 165
Jeutech 378
JVC 047 090 096 097 115 174 192 222 240 274 275 276 277 311 332 370 402 449 460 476 488 489 490 491 492 493 494 495
Kawasaki 160
Kenwood 019 039 157 197 202 256 260 261 315 335 363 400
Kingavon 382
Kiss 372 383
KLH 160 195 221
Koda 382
Konka 029
Koss 060 159 170 228
KXD 384
Lasonic 081
Lawson 377
Lecson 375

Lenco 382
Lenox 169
LG 059 270 346 407 410 414 451 477 483
Life 342 343 344
Lifetec 342 343 344 357
Limit 377
Liquid Video 170
Lite-On 272
Loewe 341 437 471
LogicLab 377
Luxor 389
Magnavox 002 018 045 051 147 176 187 190 194 370 382 395
Magnum 357
Marantz 034 190 250 350 458 472
Matsui 423
MBO 366
Mediencom 374
Medion 324 342 343 344 357 386
Memorex 003 146
Metz 339
Mico 376
Micromaxx 342 343 344 357
Micromedia 370
Micromega 401
Microsoft 189
Microstar 342 343 344 357
Mintek 004 195
Mirror 386
Mitsubishi 021 030 123 142 186 188 337 396
Mizuda 382 384
Monyka 372
Mustek 354 404 470
Mx Onda 376
NAD 059 139 364
Naiko 389
Nakamichi 116 368

Nesa 195

Neufunk 372
Nexxtech 140
Norcent 005 117 164 168 262
Nu-Tec 371
Omni 374
Onkyo 006 024 158 187 235 345 370 395
Optim 375
Optimus 398
Orava 382
Orion 054
Oritron 009 159 170 344
P&B 382
Pacific 377
Palsonic 373
Panasonic 066 075 076 153 154 155 156 157 187 197 202 203 219 225 226 245 246 248 259 279 281 284 303 306 307 308 310 317 318 319 321 335 394 467 474 478 487
Philips 002 017 018 032 036 045 073 088 091 109 176 187 190 194 206 208 234 237 241 280 283 285 296 313 333 341 350 370 395 401 416 421 422 425 428 436 441 446 447 458 473
Pioneer 008 016 143 172 191 201 224 236 243 251 282 290 339 398 479
Polaroid 007 184 221 264
Polk Audio 190
Presidian 194
Proceed 193
Proline 389
Proscan 010 033 118 189 233
Provision 382
Qwestar 009 159 265
Raite 372

RCA 010 042 048 055 063 077 099 107 118 149 152 160 189 191 195 198 210 253 291 294 302 312 355
REC 373 374
RedStar 388
Regent 169
Reoc 377
Revoy 383
Roadstar 373 382 455
Rotel 192
Rowa 161 371 389
Rownsonic 380
Saba 408 423
Sabaki 377
Sampo 119 356
Samsung 012 046 049 074 085 102 150 157 162 175 177 181 185 200 204 218 223 298 314 320 338 403 452 464 480 482
Sansui 054 071 146 300 376 377
Sanyo 050 120 134 144 146 426 461
ScanMagic 404
Schneider 322 323 324 344
Scientific Labs 377
Scott 392 412
SEG 322 362 372 377 409 420 444
Sensory Science 272
Sharp 013 015 044 086 194 207 215 287 297 342 364 463 469
Sherwood 121 361
Shinco 355
Shinsonic 173
Sigmatek 384
Silva 388
Singer 376 377
Skymaster 353 354 377 420
Skyworth 388
SM Electronic 377

Sony 014 020 022 065 068 069 070 087 103 108 113 173 182 196 199 205 211 213 214 217 229 231 239 278 292 334 399 411 424 432 434 442 445 466 475 481
Soundmaster 377
Soundmax 377
Standard 377
Star Cluster 377
Starmedia 382
Sungale 269
Superscan 147
Supervision 377
Sylvania 002 064 073 078 092 147 194 304
Symphonic 002 194
Synn 377
TCM 342 343 344 357
Teac 160 266 339 371 377 465
Tec 388
Technics 157 202 394
Techwood 141
Telefunken 380
Tevion 342 343 344 357 377 392
Theta Digital 191
Thomson 328 329 330 331 369 397 408 457 484
Tokai 372 388
Toshiba 023 025 037 038 054 080 084 088 093 094 135 146 151 187 209 212 216 220 230 232 244 247 249 293 288 293 300 305 333 370 395 453 454 485
TruVision 384
Urban Concepts 187
Venturer 011 160
Vtrek 387
Wharfedale 347 376 377
Wintel 378

Xbox 189 397
Xlogic 377
XMS 373
Yakumo 389
Yamaha 028 157 190 197 242 286 335 358 389 394 422 435
Yamakawa 367 372
Yukai 404
Zenith 052 059 128 187 270 346 370 395



Amino (EMEA)
Buckingway Business Park
Amino (EMEA)
Swavesey
Cambridgeshire
CB24 4UQ
UK
Tel: +44 1954 234100
Fax: +44 1954 234101

Amino (Americas)
3625 Brookside Parkway
Amino (Americas)
Alpharetta
GA 30022
USA
Tel: +1 678 636 6000
Fax: +1 678 636 6001

Email: info@aminocom.com
Web: www.aminocom.com

